


INSTRUCTIONS

Premium Cross Base (for HW fiberglass flagpoles)




Includes:
4 L-Shaped Stakes
1 Peg with Removable Ground Spike
2 Legs



This product is for outdoor promotional use only and should not be left out in extreme weather conditions.

Please use common sense guidelines and do not display this product outdoors when extreme winds or storms may be present.



To set-up the Cross Base, place the legs perpendicular to each other in the shape of an X.



Insert the top, center peg into the hole at the center of the legs. After that, tighten the nut on the bottom.



If the Cross Base will be used outside, secure the ground spike to the middle of the Cross Base. Then stick the spike into the ground and use the L-shaped stakes to secure the legs by driving the stakes through the smaller holes at the ends of the feet.



Attach your banner pole to the mount at the center of the Cross Base.